

PARTS AND SERVICE MANUAL

MODEL "E-22-A" HYD. HOG AITCHBONE CUTTER MODEL "E-22" HOG HOCK CUTTER MODEL "H-30" LAMB HORN CUTTER

BEST'S DONOTHN

5570 CREEK RD., CINCINNATI, OH 45242, USA

CABLE:

TOLL FREE: 1-800-553-2378 TELEPHONE: (513) 791-9180 WEPCO 513-791-0925



ALWAYS DISCONNECT MACHINE FROM POWER SOURCE & TURN-OFF HYDRAULIC PUMP BEFORE ATTEMPTING TO PERFORM ANY REPAIRS, MAKE ANY ADJUSTMENTS OR TOUCH-UP OR SHARPEN CUTTER BLADES.

SPECIFICATIONS

POWER UNIT

4.5 GPM Electric over Oil Hydraulic Pump.

Horsepower - 10

Pressure Setting - 1,300 PSI [Pre-set]

Oil Type: Anti-wear type industrial hydraulic oils or automotive

crankcase oils having letter designations "SC", "SD",

"SE" or "SF" per SAE J183FEB80.

Viscosity: Grades 32-68 cSt (150-315) SUS at 40° C. (104° Fah.)

24 Volt DC Directional Control Valve.

Tank Capacity: 38 Liters

Transformer: 24 Volt DC 4 amp.

Overall Lg: 16 Inches (407mm)

Height: 11 Inches (279mm)

Cylinder: $1\frac{1}{2}$ " Bore x 3/4" rod x $2\frac{1}{2}$ " stroke.

Balancer: 6341600 Counterbalancer 7 Ft. (2,1 m) Cable Travel

- 1] Hydraulic power unit should be installed above the working level of this machine.
- 2] Do not readjust any pressure settings. These have been pre-set at the factory.
- 3] Connect hoses marked "PRESSURE" and "RETURN". Fit female coupling to PRESSURE hose. Fit male plug to return hose.
- 4] Wire electric motor to turn in direction indicated by arrow.
- 5] Connect standard air supply as indicated (if applicable).

HANDPIECE

- a] Install one meter of door track rail parallel with dressing chain for balancer.
- b] Couple safety chain and suspend handpiece from balancer.
- c] Adjust balancer to allow handpiece to hang at rest at animal's head level.
- d] Start power unit from remote switch mounted close to operator. (to be supplied by customer).
- e] Oil all pivot points.
- f] Cycle machine.
- g] KEEP LEFT HAND AWAY FROM CUTTER AND SWITCH OFF MOTOR WHEN NOT IN USE. ESPECIALL DURING BREAKS, MEAL TIME AND WHEN KILL IS FINISHED.

ROUTINE CARE

- 1] Wash handpiece thoroughly every night and apply rust preventative oil.
- 2] Once per week remove blades from clevis, clean and apply smear of lubricant between head faced and to pivot pin.
- 3] Reassemble for use.
- 4] If blades are blunt or chipped, use oil handstone to sharpen.
- 5] If blades are badly chipped, build up with hard facing material (gas or electric welding)
- 6] If at all posible, do not remove or change shape of flat areas at ends of blades. These are blade edge protectors. Blades are flame hardened to approximately 48 Rockwell.

OPERATOR PRECAUTIONS

(1)

Be alert at all times. Think safety.

(2)

Respect your equipment and know how to operly operate it.

(3)

Be smart and wear safety glasses. But don't wear watches, bracelets, rings or necklaces. Also don't wear loose fitting clothing or neckties.



Also wear proper footwear to eliminate the possibility of slipping.

(5)

Never place fingers, hands or any part of you person between blades of Dehorner.

If a blade jams, notify supervisor or maintenant department.

PARTS LIST

PART NR.		REF. NR.	DESCRIPTION
			· -
9730100		21	Trigger
9756700		23	Pistol Grip Handle Only 2-Hole
9756800		23	Pistol Grip Handle Only 4-Hole
9739903		24	3-Way Air Valve
9739905		25	Adjustable "L" Fitting
9739907		26	Hose Fitting
9754900		27	Hose
9730800		28	Connector
9730900		29	Air Hose 3/16" (5m)
9731000	**	30	Pincer Blade (matched pair with #9732700)
9734500		32	Hanger Ring Assy
9731300	+	33	Cylinder Head (order under Part #9735250)
9731400	*	34	"O" Ring (order under Part #9735050)
9731500	*	35	"O" Ring (order under Part #9735050)
9731600		36	Cam Link
9731700		37	Yoke
9731800	*	38	Piston Seal, G.T. Type & Back Up Rings (order under Part #9735050)
9731900	+	39	Piston Rod & Piston (order under Part #9735250)
9732000	+	40	Motor Cylinder (order under Part #9735250)
9732100		41	Reducing Nipple (hex)
9732100		42	Return Socket, Cylinder
9732300		43	Power Plug, Cylinder
9732300		44	Reducing Nipple (hex)
9732500		45	Nut, Blade Pivot Bolt
9732500		46	Blade Pivot Bolt
9732700	⊹ ⊁	47	Blade (matched pair with #9731000)
9732700		48	Clevis Tube
9732900		49 -	Hanger Pivot Bolt (2 req)
9733000	*	50	Rod Scraper Seal (order under Part #9735050)
9733100		51	Cam Stud Nut (2 req)
9733100		52	Cam Stud (2 req)
9733300		53	Cam Link
9733400		54	Yoke Pin
9733500		55	Switch
9733600		56	Screw Handle (2 req)
9733700		57	Handle
9733800		58	Waterproof Pad
9733900		59	Grommet Base (with 9734000 & 9734100)
9733900		60	Grommet Washer
9734000		61	Grommet Nut (with 9733900 & 9734000)
9734100		62	Electrical Lead - Short with Connector
7/34200		04	Piccelled head broth with towns

^{**} ORDER UNDER PART #9731050

PARTS LIST


PART NR.	REF. NR.	DESCRIPTION
9734300	64	Dogleg Cam Link
9734400	65	Scissor Blades
9754200	6 6	Guard for Pistol Grip Handle
9900204	67	Screw
9756755	++ 68	Pistol Grip Handle Complete
* 9731400	- 9731500 - 97318	00 - 9733000 SOLD ONLY AS A COMPLETE SEAL
	UNDER PART #97350	


+ 9731300 - 9731900 - 9732000 CYLINDER COMPLETE UNDER PART #9735250.

ACCESSORIES (NOT ILLUSTRATED)

9736000 9736100	Electric Lead: Long with Connector Electric Connector: male for short lead
9736200	Electric Connector: female for long lead
9736300	Return Plug, Hose
9736400	Power Socket, Hose
9736500	Hose, Power or Return (2 Req)
9736700	Relay Control Box
9736800	Reducing Bushing, Hose to Solenoid
	Valve (2 Req)
9736900	Spacer / Stroke Limiter
9737000	Hydraulic Hose - Short


NOTE:







H Includes Part No.'s 9730100, 9756700, 9739903, 9739905, 9739907, 9754900, 9730800, 9730900, 9754200 & 9900204


PARTS DIAGRAM








"E-22-A" Hyd. Aitchbone Cutter





INVEST IN THE BEST...BUY B&D PACKER APPROVED MACHINES

USDA APPROVED



BEST & DONOVAN

5570 Creek Road. Cincinnati. OH 45242, USA

TOLL FREE: TELEPHONE: CABLE: FAX: 1-800-553-2378 (513) 791-9180 WEPCO 513-791-0925

